


REF.: A1274



Dimmable Switch



With a quick touch, the lamp will be turned on, and then a quick touch again to turn it off. Keep on the touch dimmable switch, the lamp will be automatic dimmable from 10% to 100% or from 100% to 10%.



WARNING

La manera correcta de conectar los cables.

The correct way to connect the cables.



BROWN CABLE

BLUE CABLE

Solo par uso en interiores / Indoor use only

Fuente de luz NO reemplazable / Light source NON-replaceable

aromas

